



3RG - 17205 - Fuelle lado cambio

Fuelle lado cambio

Referencias O.E.M: 328781;

Aplicación: CITROËN: BERLINGO / BERLINGO FIRST Furgoneta/monovolumen (M_) , BERLINGO / BERLINGO FIRST Monospace (MF_ , GJK_ , GFK_) , C3 I (FC_ , FN_) , C4 Coupé (LA_) , C4 I (LC_) , C5 Furgón/ranchera familiar (DE_ , RE_) , C5 I (DC_) , C5 I Break (DE_) , C5 II (RC_) , C5 II Break (RE_) , JUMPY (U6U_) | DISPATCH , JUMPY Furgón (BS_ , BT_ , BY_ , BZ_) | DISPATCH , XANTIA (X1_ , X2_) , XANTIA Break (X1_ , X2_) , XANTIA Furgón/ranchera familiar (X2_) , XSARA (N1) , XSARA Break (N2) , XSARA Coupé (N0) , XSARA Furgón/ranchera familiar , XSARA Furgoneta/hatchback (N3_) , XSARA PICASSO (N68) , ZX (N2) , ZX Break (N2) , ZX Furgoneta/hatchback (N2) ; PEUGEOT: 206 CC (2D) , 206 Fastback (2A/C) , 206 Sedán , 206 SW (2E/K) , 206 Van , 207 SW (WK_) , 306 (7B, N3, N5) , 306 Break (7E, N3, N5) , 306 Descapotable (7D, N3, N5) , 306 Fastback (7A, 7C, N3, N5) , 306 Furgón/ranchera familiar (N_ , 7_) , 306 Furgoneta/hatchback , 307 (3A/C) , 307 Break (3E) , 307 CC (3B) , 307 Sedán , 307 SW (3H) , 307 SW Furgón/ranchera familiar (3E_ , 3H_) , 405 II (4B) , 405 II Break (4E) , 406 (8B) , 406 Break (8E/F) , 406 Coupé (8C) , 407 (6D_) , 407 SW (6E_) , 407 SW Furgón/ranchera familiar (6E_) , 605 (6B) , PARTNER Caja/Chasis (5_ , G_) , PARTNER Furgoneta/monovolumen (5_ , G_) | RANCH , PARTNER Monospace (5_ , G_) | RANCH