



3RG - 22218 - Horquilla embrague

Horquilla embrague

Referencias O.E.M: 211766;

Aplicación: CITROËN: BERLINGO / BERLINGO FIRST Furgoneta/monovolumen (M_) , BERLINGO / BERLINGO FIRST Monospace (MF_, GJK_, GFK_) , BERLINGO Furgoneta/monovolumen (B9) , BERLINGO MULTISPACE (B9) , C2 (JM_) , C3 I (FC_, FN_) , C3 II (SC_) , C3 PICASSO (SH_) , C4 Coupé (LA_) , C4 GRAND PICASSO I (UA_) , C4 I (LC_) , C4 I Sedán , C4 II (NC_) , C4 PICASSO I Monospace (UD_) , C5 I (DC_) , C5 I Break (DE_) , C5 II (RC_) , C5 II Break (RE_) , C5 III (RD_) , C5 III Break (RW_) , C8 (EA_, EB_) , DS3 (SA_) , JUMPER Autobús (244, Z_) | RELAY , JUMPER Caja/Chasis (244) | RELAY , JUMPER Furgón (244) | RELAY , JUMPY (U6U_) | DISPATCH , JUMPY (VF7) | DISPATCH , JUMPY Furgón | DISPATCH , XSARA PICASSO (N68) ; FIAT: SCUDO Autobús (270_, 272_) , SCUDO Caja/Chasis (270_, 272_) , SCUDO Furgón (270_, 272_) ; PEUGEOT: 1007 (KM_) , 206 CC (2D) , 206 Fastback (2A/C) , 206 SW (2E/K) , 207 (WA_, WC_) | 207/207+ , 207 CC (WD_) , 207 SW (WK_) , 3008 Monospace (0U_) , 307 (3A/C) , 307 Break (3E) , 307 CC (3B) , 307 SW (3H) , 308 CC (4B_) , 308 I (4A_, 4C_) , 308 SW I (4E_, 4H_) , 406 (8B) , 406 Break (8E/F) , 407 (6D_) , 407 SW (6E_) , 5008 (0U_, 0E_) , 508 I (8D_) , 508 SW I (8E_) , 607 (9D, 9U) , 806 (221) , 807 (EB_) , BOXER Autobús (244, Z_) , BOXER Caja/Chasis (244) , BOXER Furgón (230L) , BOXER Furgón (244) , EXPERT (224_) , EXPERT Furgón (222) , EXPERT Furgón (VF3A_, VF3U_, VF3X_) , EXPERT TEPEE (VF3X_) , PARTNER Furgoneta/monovolumen , PARTNER Furgoneta/monovolumen (5_, G_) | RANCH , PARTNER Monospace (5_, G_) | RANCH , PARTNER TEPEE