



3RG - 24222 - Guia embrague

Guia embrague

Referencias O.E.M: 210514;210538;

Aplicación: CITROËN: AX (ZA-_) , BERLINGO / BERLINGO FIRST Furgoneta/monovolumen (M_) , BERLINGO / BERLINGO FIRST Monospace (MF_ , GJK_ , GFK_) , BX (XB-_) , BX Break (XB-_) , C-ELYSEE (DD_) , C1 II (PA_ , PS_) , C15 Furgoneta/monovolumen (VD_) , C15 Ranchera familiar , C2 (JM_) , C2 ENTERPRISE (JG_) , C3 I (FC_ , FN_) , C3 II (SC_) , C3 III (SX) , C3 Pluriel (HB_) , C4 CACTUS , C4 Coupé (LA_) , C4 I (LC_) , DS3 (SA_) , DS3 Descapotable , NEMO Furgoneta/monovolumen (AA_) , NEMO Monospace , SAXO (S0 , S1) , XSARA (N1) , XSARA Break (N2) , XSARA Coupé (N0) , ZX (N2) , ZX Break (N2) ; DS: DS 3 (SA_) , DS 3 Descapotable (SB_) ; FIAT: FIORINO Furgoneta/monovolumen (225_) , QUBO (225_) ; MINI: MINI (R50 , R53) ; NISSAN: MICRA II (K11) ; PEUGEOT: 1007 (KM_) , 106 I (1A , 1C) , 106 II (1A_ , 1C_) , 106 Van II Furgoneta/hatchback (1S_) , 108 , 2008 I (CU_) , 205 I Descapotable (741B , 20D) , 205 II (20A/C) , 206 CC (2D) , 206 Fastback (2A/C) , 206 Sedán , 206 SW (2E/K) , 206 Van , 206+ (2L_ , 2M_) , 207 (WA_ , WC_) | 207/207+ , 207 CC (WD_) , 207 Furgoneta/hatchback (WA_ , WC_) , 207 Sedán , 207 SW (WK_) , 208 Furgoneta/hatchback (CR_) , 208 I (CA_ , CC_) , 301 , 306 (7B , N3 , N5) , 306 Break (7E , N3 , N5) , 306 Descapotable (7D , N3 , N5) , 306 Fastback (7A , 7C , N3 , N5) , 306 Furgoneta/hatchback , 307 (3A/C) , 307 Break (3E) , 307 CC (3B) , 307 SW (3H) , 309 I (10C , 10A) , 309 II (3C , 3A) , 405 I (15B) , 405 I Break (15E) , 405 II (4B) , 405 II Break (4E) , BIPPER (AA_) , BIPPER TEPEE , PARTNER Caja/Chasis , PARTNER Furgoneta/monovolumen , PARTNER Furgoneta/monovolumen (5_ , G_) | RANCH , PARTNER Monospace (5_ , G_) | RANCH