



3RG - 40231 - Soporte motor derecho

Soporte motor derecho

Referencias O.E.M: 180754;

Aplicación: CITROËN: AX (ZA-_) , BERLINGO / BERLINGO FIRST Furgoneta/monovolumen (M_) , BERLINGO / BERLINGO FIRST Monospace (MF_ , GJK_ , GFK_) , BX (XB-_) , BX Break (XB-_) , C15 Furgoneta/monovolumen (VD_) , C4 Coupé (LA_) , C4 I (LC_) , C5 II (RC_) , C5 II Break (RE_) , C8 (EA_ , EB_) , EVASION Monospace (22, U6) | SYNERGIE , JUMPY (U6U_) | DISPATCH , JUMPY Caja/Chasis (BU_ , BV_ , BW_ , BX_) | DISPATCH , JUMPY Furgón (BS_ , BT_ , BY_ , BZ_) | DISPATCH , SAXO (S0, S1) , VISA , VISA Descapotable , XANTIA (X1_ , X2_) , XANTIA Break (X1_ , X2_) , XM (Y3) , XM (Y4) , XM Break (Y3) , XM Break (Y4) , XSARA (N1) , XSARA Break (N2) , XSARA Coupé (N0) , XSARA PICASSO (N68) , ZX (N2) , ZX Break (N2) ; FIAT: SCUDO Autobús (220_) , SCUDO Furgón (220_) , ULYSSE (179_) , ULYSSE (220_) ; LANCIA: PHEDRA (179_) , ZETA (22_) ; PEUGEOT: 106 I (1A, 1C) , 106 II (1A_ , 1C_) , 205 Furgoneta/hatchback , 205 I (741A/C) , 205 I Descapotable (741B, 20D) , 205 II (20A/C) , 206 Fastback (2A/C) , 206 SW (2E/K) , 305 II (581M) , 305 II Break (581E) , 306 (7B, N3, N5) , 306 Break (7E, N3, N5) , 306 Descapotable (7D, N3, N5) , 306 Fastback (7A, 7C, N3, N5) , 307 (3A/C) , 307 Break (3E) , 307 CC (3B) , 307 SW (3H) , 309 I (10C, 10A) , 309 II (3C, 3A) , 405 I (15B) , 405 I Break (15E) , 405 II (4B) , 405 II Break (4E) , 406 (8B) , 406 Break (8E/F) , 406 Coupé (8C) , 407 (6D_) , 407 SW (6E_) , 605 (6B) , 607 (9D, 9U) , 806 (221) , 807 (EB_) , EXPERT (224_) , EXPERT Caja/Chasis , EXPERT Caja/Chasis (223) , EXPERT Furgón (222) , PARTNER Furgoneta/monovolumen (5_ , G_) | RANCH , PARTNER Monospace (5_ , G_) | RANCH