



3RG - 70201 - Soporte escape

Soporte escape

Referencias O.E.M: 175540;175534;

Aplicación: AIXAM: 400 , 500 Fastback , A.721 , A.741 , A.751 , CITY , COUPE , CROSSLINE , CROSSOVER , D-TRUCK Caja/Chasis , D-TRUCK Furgón , D-TRUCK Pick-up , GTO , MEGA , ROADLINE , SCOUTY Descapotable ; CITROËN: AX (ZA-_) , BX (XB-_) , BX Break (XB-_) , C15 Furgoneta/monovolumen (VD_) , C15 Ranchera familiar , GS , GS Break , LNA , SAXO (S0, S1) , VISA , VISA Descapotable ; IVECO: DAILY I Caja/Chasis , DAILY II Caja/Chasis ; LIGIER: AMBRA , NOVA ; MERCEDES-BENZ: T1/TN Caja/Chasis ; MICROCAR: MC 1 , VIRGO ; PEUGEOT: 104 , 104 Coupé , 106 I (1A, 1C) , 106 II (1A_, 1C_) , 205 Furgoneta/hatchback , 205 I (741A/C) , 205 I Descapotable (741B, 20D) , 205 II (20A/C) , 305 I (581A) , 305 I Break (581D) , 305 II (581M) , 305 II Break (581E) , 306 (7B, N3, N5) , 306 Descapotable (7D, N3, N5) , 306 Fastback (7A, 7C, N3, N5) , 309 I (10C, 10A) , 309 II (3C, 3A) , 405 I (15B) , 405 I Break (15E) , 405 II (4B) , 405 II Break (4E) , 505 (551A) , 505 Break (551D) ; TALBOT: SAMBA , SAMBA Descapotable