



3RG - 84244 - Accionador bloqueo maletero (2 pins)

Accionador bloqueo maletero (2 pins)

Referencias O.E.M: 661502;

Aplicación: CITROËN: AX (ZA-_) , BX (XB-_) , BX Break (XB-_) , EVASION Monospace (22, U6) | SYNERGIE , XANTIA (X1_ , X2_) , XM (Y4) , ZX Break (N2) ; PEUGEOT: 106 I (1A, 1C) , 106 II (1A_ , 1C_) , 205 Furgoneta/hatchback , 205 I (741A/C) , 205 I Descapotable (741B, 20D) , 205 II (20A/C) , 306 (7B, N3, N5) , 306 Break (7E, N3, N5) , 306 Descapotable (7D, N3, N5) , 306 Fastback (7A, 7C, N3, N5) , 306 Furgoneta/hatchback , 309 I (10C, 10A) , 309 II (3C, 3A) , 405 I (15B) , 405 II (4B) , 405 II Break (4E) , 406 (8B) , 406 Break (8E/F) , 406 Coupé (8C) , 806 (221)